


SERIES 5F / 5J Molded Solenoid Valve Connector
Wiring Diagram




TERMINAL CONFIGURATION				
Wire Type	Chassis Ground 	(+) Positive / Hot Pin 1	(-) Negative / Neutral Pin 2	Signal Pin 3
EUR	yellow & green	brown	blue	black
US / HU	green	black	white	red

Note: Slight discoloration may occur to translucent material after prolonged exposure to UV rays.

A56-1354 Rev. 01

SERIES 5F / 5J Molded Solenoid Valve Connector
Wiring Diagram




TERMINAL CONFIGURATION				
Wire Type	Chassis Ground 	(+) Positive / Hot Pin 1	(-) Negative / Neutral Pin 2	Signal Pin 3
EUR	yellow & green	brown	blue	black
US / HU	green	black	white	red

Note: Slight discoloration may occur to translucent material after prolonged exposure to UV rays.

A56-1354 Rev. 01

SERIES 5F / 5J Molded Solenoid Valve Connector
Wiring Diagram




TERMINAL CONFIGURATION				
Wire Type	Chassis Ground 	(+) Positive / Hot Pin 1	(-) Negative / Neutral Pin 2	Signal Pin 3
EUR	yellow & green	brown	blue	black
US / HU	green	black	white	red

Note: Slight discoloration may occur to translucent material after prolonged exposure to UV rays.

A56-1354 Rev. 01

SERIES 5F / 5J Molded Solenoid Valve Connector
Wiring Diagram



TERMINAL CONFIGURATION				
Wire Type	Chassis Ground 	(+) Positive / Hot Pin 1	(-) Negative / Neutral Pin 2	Signal Pin 3
EUR	yellow & green	brown	blue	black
US / HU	green	black	white	red

Note: Slight discoloration may occur to translucent material after prolonged exposure to UV rays.

A56-1354 Rev. 01